


825-DIO 825 Digital Input/Output Card Installation Guide

INSTALLATION



Figure No. 1

- **1.** If the rear panel of the indicator has been removed, proceed to step 2. Otherwise, remove the 14 acorn nuts securing the rear panel to the main housing.
- **2.** Referring to Figure No. 1, choose a gland connector for the I/O cable.
- **3.** Loosen and remove the gland connector nut and remove the plastic plug.
- **4.** Slip the cable through the gland connector and into the enclosure.
- 5. Referring to Figure No. 2, remove 3 inches of the outer insulation jacket.
- **6.** Next, remove 1/4 inch of insulation from each of the wires.
- Referring to the corresponding I/O tables and figures in the next sections, connect each wire to the terminal block.



- **8.** To terminate a wire, loosen the screws in the terminal block and then insert the wire into the terminal opening. Tighten the screw to secure the wire in place.
- 9. Repeat the procedure until all wires are in place.

825-DIO Digital Input/Output Card

The 825-DIO Digital Input/Output card has been designed for the industrial environment where interfacing to switches, sensors, or AC loads (using the optional Cardinal RB8-OPTO relay box) are desired. The 825-DIO when coupled with the 825 Digital Weight Indicator provides a complete input and output system. The customer can program the functions of the eight inputs and outputs from the 825 without the need for complicated programming devices.


The 825-DIO card resides in the 825 main enclosure, has a PCI Express Bus (PCIe) connector and is secured by a single screw to provide an easy connection to the 825 internal hardware.


Features

PCI Express Connector

- 8 Isolated I/O Channels (when J1 & J2 are removed).
- Each channel can be configured as an input or output.
- 2500 Vrms isolation.
- 150mA sink current on output channels.
- Outputs can drive inductive loads like mechanical relays.
- Up to 24V input.


Mounting Screw






CONNECTION DIAGRAMS

Non-Isolated Input (J1 & J2 Installed)




Isolated Input (J1 & J2 Removed)




CONNECTION DIAGRAMS, Cont.

Non-Isolated Output (J1 & J2 Installed)



Isolated Output (J1 & J2 Removed)



Cardinal Scale Mfg. Co.

102 E. Daugherty, Webb City, MO 64870 USA Ph: 417-673-4631 or 1-800-641-2008 Fax: 417-673-2153 www.cardinalscale.com

Technical Support: 1-866-254-8261 E-mail: tech@cardet.com

Printed in USA 825-DIO Installation Guide